Manualslib.com - The Global Manuals Library

PHILIPS HR2041 USER MANUAL



Table of Contents

Overheat Protection

Other ManualsLib Projects

PHILIPS

HR2041



EN	**User manual**
DA	**Brugervejledning**
DE	**Benutzerhandbuch**
EL	**Εγχειρίδιο χρήσης**
ES	**Manual del usuario**
FI	**Käyttöopas**
FR	**Mode d'emploi**
HE	**מדריך למשתמש**
IT	**Manuale utente**
NL	**Gebruiksaanwijzing**
NO	**Brukerhåndbok**
PT	**Manual do utilizador**
SV	**Användarhandbok**
BG	**Ръководство за потребителя**
CS	**Příručka pro uživatele**
ET	**Kasutusjuhend**
HR	**Korisnički priručnik**
HU	**Felhasználói kézikönyv**
KK	**Қолданушының нұсқасы**
LT	**Vartotojo vadovas**
LV	**Lietotāja rokasgrāmata**
MK	**Упатство за користење**
PL	**Instrukcja obsługi**
RO	**Manual de utilizare**
RU	**Руководство пользователя**
SK	**Príručka užívateľa**
SL	**Uporabniški priročnik**
SQ	**Manual përdorimi**
SR	**Korisnički priručnik**
UK	**Посібник користувача**
TR	**Kullanım kılavuzu**

1

optional

HR2041/10
HR2041/15
HR2041/30
HR2041/32
HR2041/50


optional


HR2041/30
HR2041/32


optional


HR2041/41


2













5



6
P
1



7
0
1
P
2



8


3


optional


















4


optional
















6
1
0 . . . 1
P
≤ 60 sec.


7
0
0 . . . 1
P


8


9
1
2


10
2
1


11


5


		Kg (MAX)		(MAX)
		1000 ml	1	60 - 90 sec.
		1000 ml	1	60 - 90 sec.
		1000 ml	1	30 - 60 sec.
		6 x	P	1 min
optional		200 g / 300 ml	1	1 min
optional		200 g / 250 ml	1	1 min
optional		30 g	1	10 sec
optional		50 g	P	10 sec
optional		50 g	P	10 sec
optional		25-50 g	P	30 sec
optional		5-25 g	P	30 sec
optional		25-75 g	P	30 sec
optional		5-15 g	P	10 sec


2x2x2 cm


6










	✓	✓	✓
	✗	✗	✓



English

Introduction

Congratulations on your purchase and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at **www.philips.com/welcome**.

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the motor unit in water or any other liquid, nor rinse it under the tap. Use only a moist cloth to clean the motor unit.

Warning

- Thoroughly clean the parts that come into contact with food before you use the appliance for the first time.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the mains cord or other parts are damaged.
- Never use the blender jar or accessories to switch the appliance on and off.
- Never let the appliance run unattended.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Children shall not play with the appliance.
- Do not touch the blades, especially when the appliance is plugged in. The blades are very sharp.
- Do not pour hot liquid into the food processor or blender as it can be ejected out of the appliance due to a sudden steaming.
- The appliance is intended to be used in household only.

Caution

- Switch off the appliance and always disconnect from supply if it is left unattended and before assembling, disassembling, approaching parts that move in use or cleaning.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your warranty becomes invalid.
- Do not exceed the maximum indication on the blender jar and the mill/chopper .
- Do not exceed the maximum quantities and processing times indicated in the relevant table.
- The appliance can only be switched on if the blender jar or the mill/chopper is assembled on the motor unit correctly.

Blender

Warning

- Never reach into the blender jar with your fingers or an object while the appliance is running.
- Make sure the blade unit is securely fastened to the blender jar before you assemble the blender jar onto the motor unit.
- Do not touch the cutting edges of the blender blade unit when you handle or clean it. They are very sharp and you could easily cut your fingers on them.
- If the blade unit gets stuck, unplug the appliance before you remove the ingredients that block the blades.

Caution

- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- Do not misuse the appliance to avoid potential injury.
- Never fill the blender jar and accessories with ingredients hotter than 60°C.
- Do not use the glass blender jar right after taking it out from dishwasher or refrigerator. Let it stay at room temperature for at least 5 minutes before use.
- To prevent spillage, do not exceed the maximum volume indication on the blender jar, especially when you process at a high speed. Reduce amount of the ingredient that tends to foam in the jar/accessory.
- If food sticks to the wall of the blender jar, switch off the appliance and unplug it. Then use a spatula to remove the food from the wall.
- Always make sure the lid is properly closed/assembled on the jar and the measuring cup if any is inserted properly in the lid before you switch on the appliance.

- Do not let appliance run for more than 2 minutes at time.
- Always let the appliance cool down to room temperature after each batch you process.
- Noise level: Lc = 86dB(A)

Mill/Chopper

Warning

- Make sure the blade unit is securely fastened to the mill/chopper before you assemble the mill/chopper onto the motor unit.
- Never use the mill/chopper to grind very hard ingredients such as nutmeg, rock sugar and ice cubes.
- Do not touch the cutting edges of the mill/chopper blade unit when you clean it. They are very sharp and you could easily cut your fingers on them.

Caution

- Never use the mill/chopper for more than 30 seconds without interruption.
- Always let the appliance cool down to room temperature after each operation.

Built-in safety lock

This feature ensures that you can only switch on the appliance if the blender jar or accessories is assembled on the motor unit properly. If the blender jar or accessories is correctly assembled, the built-in safety lock will be unlocked.

Overheat protection

The appliance is equipped with overheat protection. If the appliance overheats, it switches off automatically (which might occur during heavy processing jobs or if the appliance is not used according to the instructions in the user manual). If this happens, first switch off and unplug the appliance and let it cool down to room temperature. Then check if the quantity of ingredients you are processing does not exceed the quantity mentioned in the user manual or if something is blocking the blade unit. Then put the mains plug back into the power outlet and switch on the appliance again.

Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Recycling



This symbol means that this product shall not be disposed of with normal household waste (2012/19/EU).

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Warranty and support

Versuni offers a two-year warranty after purchase on this product. This warranty is not valid if a defect is due to incorrect use or poor maintenance. Our warranty does not affect your rights under law as a consumer. For more information or for invoking the warranty, please visit our website **www.philips.com/support**.

www.philips.com/welcome

PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.
This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.
2023 © Versuni Holding B.V.
642001003987 (24/10/2023)

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ Languages